

POLICRETE INDUSTRIAL FLOOR SYSTEM

PREPARATION

STEP 1

SURFACE PREPARATION



STEP 2

WITH SILICA SAND BED MOISTURE
VAPOR BARRIER

SEALOK
1 Coat



STEP 3

POLYUREA FAST CURE

FASTEX
2 Coats



STEP 4

TOPCOAT POLYUREA LOW GLOSS,
MEDIUM GLOSS AND GLOSS

ULTRASEAL
2 Coats

