

POLICRETE INDUSTRIAL FLOOR SYSTEM WITH LEVELING

PREPARATION

STEP 1

SURFACE
PREPARATION



STEP 2

MOISTURE VAPOR BARRIER
WITH SILICA SAND BED

SEALOK
1 Coat

NO PHOTO



STEP 3

FLAT LEVELING - 1/4"

ULTRAPLAN
(OR SIMILAR)



STEP 4

POLYUREA FAST CURE

FASTEX
2 Coats



STEP 5

TOPCOAT POLYUREA LOW GLOSS,
MEDIUM GLOSS AND GLOSS

ULTRASEAL
80 sqf/gallon
1 coat

