

POLICRETE METALLIC SYSTEM

PREPARATION

STEP 1

**SURFACE
PREPARATION**



STEP 2

**MOISTURE VAPOR BARRIER
WITH SILICA SAND BED**

**SEALOK
1 Coat**



STEP 3

**FLAT LEVELING
1/4"**

**ULTRAPLAN
PLUS 1**



STEP 4

**EPOXY PRIMER
WITH SILICA SAND BED**

**BLACK BONDEX
1 Coat**



STEP 5

**EPOXY BODY COAT WITH
METALLIC PIGMENT**

**BOLTEX
80 sqf/gallon
1 coat**



STEP 6

**PROTECTIVE
COAT**

**NEWGAIN
2 Coats**

